# APPLICATION DATA SHEET



AP147-02-2019

# Product Number: 147

# Floor Fire Coat (FFC) System for Wood Floors/Stairs

### **Description:**

A hard wearing semi-gloss top coating for use on wooden floors or stairways. Used in conjunction with Envirograf® Product 42 HW01 (white or coloured) for 30/60 minutes fire protection or in conjunction with Envirograf® Product 92 ES/VFR system (clear, white or coloured) for Class 0 / Class 1 / SBI requirements.

## Application:

Option 1: Spread of flame Class 0/1 & SBI: B/S1/D0

#### Primer: ES/VFR/PRIMER Water based A clear water based primer to apply over existing paint varnish or wax surfaces before applying coatings

varnish or wax surfaces before applying coatings Coating rate: 1 coat at 10-12m<sup>2</sup> per litre

# Fire Retardant Coating: ES/VFR – CLEAR Water based ES/VFR - COLOUR Water based

Applied in 2 coats at 10m<sup>2</sup> per litre per coat Allow each coat up to 1-2 hours to dry

#### FFC/FLOOR FIRE COAT: FFC – Clear or colour Spirit based

FFC is applied in 2 coats at 12m<sup>2</sup> per litre per coat Ensure each coat is dry before applying the next coat

#### Option 2: 30-60 minute fire rating

# Primer: HWAP/WB/PRIMER Water based

A clear water based primer to apply over existing paint varnish or wax surfaces before applying coatings. Coating rate: 1 coat at 10-12m<sup>2</sup> per litre

## 30 – 60 minute Coating: HWO1/F – WHITE / COLOUR Water based

30 minutes protection: Apply 2 coats at 8m<sup>2</sup> per litre per coat
60 minutes protection: Apply 3 coats at 8m<sup>2</sup> per litre per coat

#### FFC/FLOOR FIRE COAT: FFC – Clear or colour Spirit based

FFC is applied in 2 coats at 12m<sup>2</sup> per litre per coat Ensure each coat is dry before applying the next coat

Note: Please refer to Application Data sheets for ES/VFR and HW systems for further information before applying. If further information or advice is needed please contact the Technical Department.